

Installation Instructions for footrest

- 1** The installer should measure from the trimmed end of the footrest to the first hole and then mark the first hole that distance from the back wall, keeping the hole centered so that the ledge will be aligned with the band. The second hole should be forward along the band from the first hole.
- 2** Attach SUS304 expansion screw to the wall.
- 3** Apply generous amount of silicone at the back of the footrest to full-fill the holes.
- 4** Also, the back side surface of the footrest.
- 5** Apply hot glue to the surface (or similar), to enable the footrest to quick set to the wall.
- 6** Quickly install the footrest before hot glue sets up.
- 7** Hold footrest firmly for 30 seconds.
- 8** Seal the edge with silicone.
- 9** Hot glue sets very quick, it gives time for silicone to set.

***Once silicone sets, the footrest
is permanently adhered.***