



Installation Instructions for 15" x 3" x 1.5", 27" x 3" x 1.5" Shampoo Ledge

- 1** The installer should measure from the trimmed end of the ledge to the first hole and then mark the first hole at that distance from the back wall, keeping the hole centered so that the ledge will be aligned with the band. The second hole should be forward along the band from the first hole.
- 2** Attach SUS304 expansion screw to the wall.
- 3** Apply generous amount of silicone at the back of the Shampoo Ledge to full-fill the holes.
- 4** Also, the back side surface of the Shampoo Ledge.
- 5** Apply hot glue to the surface (or similar), to enable the Shampoo Ledge to quick set to the wall.
- 6** Quickly install the Shampoo Ledge before hot glue sets up.
- 7** Hold Shampoo Ledge firmly for 30 seconds.
- 8** Seal the edge with silicone.
- 9** Hot glue sets very quick, it gives time for silicone to set.

***Once silicone sets, the Shampoo Ledge
is permanently adhered.***