

Aqua Mirrors Cultured Marble Soap Dish

Quick Installation Guide

Step-by-Step Installation

- 1 Mark Height**
Measure 48" (121.9cm) up from the shower base and mark the line – this is the top edge of the shelf.
- 2 Clean Surfaces**
Thoroughly clean the back of the shelf and wall area with acetone to ensure a strong bond.
- 3 Level the Line**
Use a torpedo level to draw a horizontal line across the corner onto the adjacent wall.
- 4 Apply Adhesives (DO NOT MIX)**
Apply a continuous bead of silicone to the shelf back, then add dots of high-temp hot melt glue around it.
- 5 Secure the Soap Dish**
Press firmly into the corner and hold for 30 seconds to set the hot melt glue.
- 6 Wipe Excess**
Remove any adhesive squeezed out from behind the shelf immediately.
- 7 Seal Joints**
Seal all gaps around the shelf with 100% color-matched silicone for a waterproof finish.
- 8 Final Cleanup**
Wipe away pencil marks and excess silicone with a clean cloth.



Aqua Mirrors Cultured Marble Soap Dish

Critical Warnings

- Never mix silicone and hot melt glue – this will ruin the bond strength.
- Install immediately after applying hot melt glue. If it cools, scrape and reapply.
- DO NOT use general-purpose glue sticks – they cannot support the shelf weight.
Recommended Glue
- Retail Alternative: Arrow Fastener 4" Super Strong Glue Stick (check local Home Depot/Lowe's for availability)

1-3155 Pepper Mill Court, Mississauga, ON L5L 4X7

(905) 820-0800

www.aquamirrors.com